



Electron Beam Irradiated Intercalated CNT Yarns For Aerospace Applications

Deborah L. Waters, James R. Gaier, Tiffany S. Williams

NASA Glenn Research Center

Johnny E. López Calero


University of Puerto Rico at Mayaguez

Christopher Ramirez

The University of Texas at El Paso

Michael A. Meador

National Science and Technology Council






Background and Goals

- Previous data suggested that yarns irradiated by an e-beam showed an improvement in tensile properties
- CNT fibers and yarns could potentially be used for multifunctional devices - electrical conductor, data line as well as a tendon for movement
- Electrical conductivity could be doubled with intercalation - 100 kS/cm is needed to equal copper's specific conductivity
- Goal: To determine the effects of intercalation and irradiation on the electrical and mechanical properties of CNT yarns

CNT Fibers

- Nanocomp Technologies
NB87 and NB106
 - “(Nanocomp Technology Inc.) production systems generate a "cotton candy" or "stocking-like" flow of millimeter-length CNTs that can be translated into multiple formats, each of which possess a different mix of strength and conductivity”, including lightweight wires and yarns

<http://www.nanocomptech.com/conductors-and-yarns>





Electron Beam



- NEOBeam is an electron beam accelerator owned by Mercury Plastics, Inc. (Middlefield OH)
- It is used to cross-link polymeric materials
- **2 MV electron beam (capable of 5 MV)**
- The electrons break C-H bonds and facilitate C-C bonds

<http://www.mercuryplastics.com/neo-beam>

Intercalation of CNT yarns



Test Matrix for NB87 and NB106

As-Received

Intercalated

E-beam for 20 min

E-beam for 40 min

Intercalated then E-beam for 20 min

Intercalated then E-beam for 40 min

E-beam for 20 min then Intercalated

E-beam for 40 min then Intercalated


- Treat CNT fibers in glass reaction vessel with a combination of **Bromine, Chlorine and Iodine**
- Halogen concentrations and temperatures were held constant for the reactions in the test matrix



Conductivity – 4-Point Probe Resistance measurement



Test Equipment



Tensile Testing – Instru- Met Corporation RENEW 1125

SEM/EDS – Hitachi S-3500N / Thermo Scientific UltraDry 4455D




Raman Spectroscopy - Renishaw System 2000 Microscope with Ar⁺ ion laser at 514 nm






Results – Conductivity With Time – NB87






Results – Conductivity With Time – NB106






Results – Conductivity (kS/cm) NB87 (solid) and NB106 (striped)






Results – Tensile Test – NB87 Int + E-beam 40 min

4 Samples Tested






Results – Normalized Strength (N/tex) NB87 (solid) and NB106 (stripes)




Results - Raman Spectroscopy


NB87 As-Received




NB87 E-beam 40 min




NB106 As-Received



NB106 E-beam 20 min






Results – Raman D/G Ratios


Fiber	As-Received	Int	EB 20 min	EB 40 min	Int + EB 20 min	Int + EB 40 min	EB 20 min + Int	EB 40 min + Int
NB87	0.12	0.28	0.09	0.27	0.22	0.07	0.29	0.23
NB106	0.17	N/A	0.32	0.23	0.21	0.09	0.24	0.28

Results – SEM NB87

As-Received




Int + E-beam 20 min






Results – SEM NB106

As-Received




Int + E-beam 20 min






Results – EDS – NB87

As-Received



E-beam 20 min





E-beam exposes the chlorine which is used in the manufacturing process



Results – EDS – NB87

Intercalated

Int + E-beam 20 min



Intercalation halogens appear and are reduced after E-beam



Conclusions

- Overall, for CNT electrical wires the NB106 performed better than the NB87 fibers in both conductivity and tensile properties
- Mechanical strength of these particular fibers is not increased with the additional step of the e-beam beyond statistical error, but could help if intercalation is done in some cases
- Conductivity decreases with time in general for these samples
 - NB87 conductivity almost doubles with intercalation, it also shows an increase for any of the other processing steps
 - NB106 conductivity approximately doubles with intercalation, intercalation before and after e-beam also shows an increase in conductivity, e-beam alone shows a decrease in conductivity



Conclusions

- Raman showed some inconsistent results and should be repeated on a different Raman for verification
- SEM generally showed some visual smoothing of NB87 surfaces after processing while the NB106 samples all appeared very similar
- EDS showed consistently that the e-beam removed the halogenated materials unless intercalation took place after the e-beam



Future Work

- Increase the conductivity of the wires through changes in reaction time, concentration and temperature
- In-situ resistance measurements during the reaction process to determine optimum conditions for intercalation
- Coat the intercalated fibers to slow the diffusion of halogens out of the fibers
- Stability of the fibers in other environments such as humidity and changing temperature
- Re-run test matrix samples on another Raman unit



Acknowledgments

Jeffrey Eldridge – NASA GRC

Marisabel Lebron Colon – NASA GRC

Azlin Biaggi Labiosa – NASA GRC

Phillip Abel – NASA GRC

Dan Scheiman – Ohio Aerospace Institute

Bradlee Beauchamp – Rose-Hulman Institute of Technology

Kiara Rivera Rodriguez – University of Puerto Rico Mayaguez

Professor Roberto Uribe – Kent State University